BRAGAMORO

3000W True Sine Wave DC-AC Inverter 12VDC

SIVCV001-A

- Features :
- True sine wave output (THD<3%)
- High surge power up to 6000W
- U.P.S. mode and energy saving mode (selectable)
- High efficiency up to 92%
- Power ON-OFF switch
- Standby saving mode can be selectable
- Front panel indicator for operation status
- Thermostatically controlled cooling fan
- Protections: Bat. low alarm / Bat. low shutdown / Over voltage / Over temp. / Output short / Input polarity reverse / Overload / AC circuit breaker
- Application : Home appliance, power tools, office and portable equipment, vehicle and yacht ...etc.
- Built-in solar / AC charger
- Support RS-232 communication (communication cable RJ11-RS232 included) Note.?



				-	3 years w	arranty		13	R[F©	СВ	Ce		
SPECIFICA	ATION	1				(for 1	UL458 12/124 type G only	/)	(fo	IEC62368-1 r 212/224/248 or	nly)		
MODEL NO		SIVCV001 12	SIVCV002	24	SIVCV003-	48	SIVCV-001A	2 5	SIVCV001-A 2	4 SIVC0	01-A	48	
		🗆 = A, F, G					□= B, C, D, G	i					
	RATED POWER (Typ.)	3000W											
OUTPUT	MAXIMUM OUTPUT POWER (Typ.)	3450W for 180 sec. /	30 cycles										
		Factory setting set at 110VAC Factory setting set at 230VAC											
	AC VOLTAGE	100 / 110 / 115 / 120VAC selectable by setting button S.W 200 / 220 / 230 / 240VAC selectabl							C selectable b	by setting butt	on S.V	V	
	FREQUENCY Note.11	60 ± 0.1 Hz 50/60Hz selectable by setting button S.W					50 ± 0.1 Hz 50/60Hz selectable by setting button S.W						
	WAVEFORM Note.8	True sine wave (THD<3%)											
	AC REGULATION (Typ.)	±3%											
	TRANSFER TIME (Typ.)	10ms inverter											
	SAVING MODE (Typ.)	Default disabled. Load ≦5W will be changed to standby mode											
	FRONT PANEL INDICATOR	Battery voltage level,	peration status										
INPUT	BAT. VOLTAGE	12V	24V		48V		12V	2	24V	48V			
	VOLTAGE RANGE (Typ.) Note.3,6	10.5 ~ 15VDC	21 ~ 30VDC		42 ~ 60VDC		10.5 ~ 15VDC	2	21 ~ 30VDC	42 ~ 6	OVDC		
	DC CURRENT (Typ.) Note.4	300A	150A		75A		300A	1	50A	75A			
	NO LOAD DISSIPATION (Typ.)	≦10W @ standby saving mode											
	OFF MODE CURRENT DRAW (Typ.)	≦1mA											
	EFFICIENCY (Typ.) Note.1	88%	90%		91%		89%	g	91%	92%			
	BATTERY TYPES	Open & sealed lead a	icid battery										
BATTERY INPUT PROTECTION	FUSE	40A*12	40A*6		20A*6		40A*12	4	0A*6	20A*6			
	BAT. LOW ALARM Note.6	11.3V	22.5V		45V		11.3V	2	22.5V	45V			
	BAT. LOW SHUTDOWN Note.6	10.5V	21V		42V		10.5V	2	21V	42V			
	REVERSE POLARITY								-00				
OUTPUT PROTECTION	OVER TEMPERATURE	90°C ± 5°C	85°C ± 5°C		85°C± 5°C		80°C ± 5°C	1	5°C± 5°C	75°C =	= 5°C		
		Protection type : Shut		age, re-	power on to n	ecover							
	OUTPUT SHORT	Protection type . Shut down 0/p voltage, re-power on to recover											
	OVER LOAD (Typ.)	Protection type : Shut down o/n voltage, re nower on to receiver											
		AC output: 40A. AC receptacle:15A					AC output: 20A AC receptacle: 15A						
		Optional (Only type F)					None						
ENVIRONMENT	WORKING TEMP. Note.2	0 ~ +40°C @ 100% load ; 60°C @ 50% load											
	WORKING HUMIDITY	20% ~ 90% RH non-	20% ~ 90% RH non-condensing										
	STORAGE TEMP., HUMIDITY	-30 ~ +70°C / -22 ~ +	158°F, 10 ~ 9	5% RH n	non-condensin	3							
	VIBRATION	10 ~ 500Hz, 3G 10m	10 ~ 500Hz, 3G 10min /1cvcle, 60min, each along X, Y, Z axes										
SAFETY & EMC	SAFETY STANDARDS	UL458 (only for Type G), EAC TP TC 004 EAC TP TC 004 IEC62368-1 CB, EAC TP TC 004 approved; Design refer to BS EN/EI								162368-1			
	WITHSTAND VOLTAGE	Bat I/P - AC I/P:3.0KVAC Bat I/P - AC O/P:3.0KVAC AC O/P - FG:1.5KVAC											
	ISOLATION RESISTANCE	Bat I/P - AC O/P, Bat I/P - FG, AC O/P - FG: 100M ohms / 500VDC / 25°C/ 70% RH											
	EMC EMISSION	Compliance to FCC of	Compliance to FCC class A, EAC TP TC 020					Compliance to BS EN/EN55032 class A, 72/ 245/ CEE, 95/ 54/ CE, E-Mark, EAC TP TC 020					
	EMC IMMUNITY	Compliance to EAC TP TC 020					Compliance to BS EN/EN61000-4-2,3,4,5,6,8,11, BS EN/EN55035, EAC TP TC 020						
AC CHARGER	CHARGE CURRENT (Typ.)	25A	12A		6A		25A	1	2A	6A			
	CHARGE VOLTAGE Note.6	14.3V	28.5V		57V		14.3V	2	28.5V	57V			
SOLAR	MAX OPEN CIRCUIT VOLTAGE	25V	45V		75V		25V	4	ISV	75V			
PANEL	SHORT CIRCUIT CURRENT (max.)	3UA											
OTHERS	CONTROL WIRING Note.7	KJII-KOZOZ											
	MTBF	100.3K IIIS IIIIII. 18001018 SK-332 (DEIICUIE); 20./K NIS MIN. MIL-HUBK-21/F (25 C)											
	DIMENSION	466.8*283.5*100mm (L*W*H)											
NOTE	1 Efficiency is tested by 2100	Lizony, ipor Hny/1.4500F1											
NUTE	 Output derating capacity references Dutput derating capacity references DC current is tested by 3000 All parameters not specified The tolerance of each voltage The cable is enclosed for the THD is tested by 3000W, ling Please do not turn on the inv The ambient temperature do 	v, mice hod ourve 1. enced by curve 2. WV, linear load at 12V above are measured le value by models is: connection between ear load at 13,26,52V refer before start the lerating of 3,5°C/1000	, 24V, 48V in at rated load, 112/212→±(TN-3000 anc input voltage engine if inve m with fanles	put volta 25°C of 0.5V;124 I compu	age. f ambient terr 4/224→±1V tter for softwa nect to vehicl Is and of 5°C/	perature ;148/248 re monito e's batter 1000m w	and set to facto $\rightarrow \pm 2V.$ pring. Ty directly. with fan models i	ory settin	ng. ating altitude h	igher than 20	00m(6	6500ft).	
	11. Type F for 60Hz only.	<u> </u>							0			/-	

SPECIFICATION

BRAGAMORO

3000W True Sine Wave DC-AC Inverter

SIVCV001-A

Instructions for SIVCV001-A monitoring software

- 1. The monitoring software can be downloaded from product section (with SIVCV001-A specification)
- 2. The monitoring software can run on Windows 7 English version, Windows 8 English version and Windows 10 English version
- 3. Installation of SIVCV001-A unit and PC





4. Explanation of Monitoring Manu





- 1. Setting: Adjustment for output voltage, charging related voltage, frequency, and operation mode. Please refer to Figure 3 for details.
- 2. Statistics: Calculate for the percentage of operating period for each operation mode. Please refer to Figure 4 for details.
- 3. R.C. Power off: Power can be turned ON or OFF at the remote location.
- 4. Pause: Stop refreshing the page of monitoring software.
- 5. Status of unit: Indicating current operating status of SIVCV001-AC
- 6. Signals that display current condition of the unit.

BRAGA MORO Sistemi di Energia S.r.I. Via S. Gregorio, 12- 20124 Milano Tel. +39.02 51672201 - Fax +39 02 51672214 sales@bragamoro.com - www.bragamoro.com